




PRE-INSTALLATION

Power input is 12V AC/DC or 120V. Confirm the source voltage is compatible. Disconnect power source prior to installation.

Fixture mounts to standard 1 Gang Junction Box (not provided by factory). Junction Box should be installed prior to step light installation.

INSTALLATION GUIDE

DIMENSIONS



SAFETY

Read all instructions before installation.

Do not look directly into light.

Do not submerge in water.

 \triangle

Product should be installed by a qualified electrician.



Product should be installed in accordance with these instructions and current electrical codes.



Not recommended to be installed on the beach and corrosive chemical areas to avoid corrosion and damage.



Must be installed with CORE Lighting Drivers

INSTALLATION

STEP 4

STEP 1

Feed the main power cable through the pre-installed junction box. (Figure 1)

Fix the face plate of choice to the trim plate. Using the provided screws, secure the face plate and trim plate combo to the LED module from the back of the module. (Figure 2)

*Refer to spec sheet for face plate options

STEP 3

Connect the main power cable and fixture wires. (Figure 3)

secure in place with screws. (Figure 4)

Align the assembled light fixture to the junction box and

